

IP Camera RTSP URL address

TH/MC/HC/A series:

Sub-stream: rtsp://username:password@ip/stream1

Main-stream: rtsp://username:password@ip/stream0

Example:

If the IP address of the camera is 192.168.1.123, then the RTSP URL of this camera is as follows:

Main-stream: rtsp://admin:123456@192.168.1.123/stream0

Sub-stream: rtsp://admin:123456@192.168.1.123/stream1

DM/Bseries:

Sub-stream: rtsp://ip/1

Main-stream: rtsp://ip/0

Example:

Main-stream: rtsp://192.168.1.123/0

Sub-stream: rtsp://192.168.1.123/1

General Address:

Sub-stream: rtsp://username:password@ip:port/mpeg4cif

Main-stream: rtsp://username:password@ip:port/mpeg4

Example:

If the IP address of the camera is 192.168.1.123, then the RTSP URL of this camera is as follows:

Main-stream: rtsp://admin:123456@192.168.1.123:554/mpeg4

Sub-stream: rtsp://admin:123456@192.168.1.123:554/mpeg4cif